




Blende demontieren
Bitte benutzen Sie nur ein Kunststoff-Werkzeug!



Remove covering
Please use only plastic tools!



Unteres Blech einhaken



Hook in lower metal plate



Oberes Blech umbiegen



Bend upper metal plate




Änderungen vorbehalten Subject to change



Demontér l'écran
Veuillez n'utiliser qu'un outil de matière plastique



Desmante el revestimiento
Use sólo herramientas de plástico!



Accrochez la tôle inférieure



Enganche la chapa inferior



Tordez la tôle de dessus



Tuerza la chapa arriba




Nous nous réservons la possibilité de modification Salvo posibles modificaciones



Afdekschild demonteren
Alleen plastic gereedschap gebruiken alstublieft!



Zdemontować osłone
Proszę używać tylko narzędzi z tworzywa sztucznego.



Onderste metalen lip inhaken



Zaczepić dolną blaszkę



Bovenste plaat ombuigen



Górna blaszka zagiąć



Nous nous réservons la possibilité de modification Salvo posibles modificaciones